

Web: <http://clearsound.club/#>

E-mail: master@clearsound.club

Classique: audiophile player

Please, note that is an evaluation version, there are pauses during playback.

Supported formats:

pcm: aiff, wav, flac, alac

cue files

Installation.

Installation is not required. Unpack the archive to a suitable location on the disk.

You can make multiple copies in folders with different names. In this case each instance has its own settings.

Customization.

At the first launching, a list box of the ASIO driver appears after the initial splash screen. Just click on the desired and active ASIO driver.

In the future, if a selected DAC is active, and its internal settings are unchanged, the setup mode is skipped when you start the player.

To enter the setup mode, when starting the player, click on the initial screen saver or press the "Enter" button.

When you select the ASIO driver, a settings window appears. Here you can set the initial volume level and adjust the configuration of the player.

Control.

To control the player, use the on-screen buttons.

Short keys:

"U" or "+" in the keypad – volume increase

"D" or "-" in the keypad – volume decrease

"P" – play

"S" – stop

"N" – the next track

"Space" – play / pause

"Up" – scroll up

"Down" – scroll down

"Shift + Up" – move a track one position up

"Shift + Down" – move a track one position down

"Delete" – delete a track

"C" – clear playlist

Covers.

The format of the cover is "png" or "jpg"

The name of the cover is "cover", "front" or "folder"

The location of the cover - where the tracks are, or in the subdirectory "Art"

Other.

The ASIO driver buffer is set on the value recommended by the DAC manufacturer or higher.

You can open tracks only with the same sample rate at the same time.