

Web: <http://clearsound.club/#>

E-mail: clearsound.club@gmail.com

July Dream: Hi-End audio player

Please, note that is an evaluation version, there are pauses during playback.

Supported formats:

pcm: aiff, wav, flac & cue files

Installation.

Installation is not required; you just need to unpack the archive in suitable disk space.

You can make multiple copies in folders with different names. In this case each instance has its own settings.

Customization.

At the first launching, a list box of the ASIO driver appears after the initial splash screen. Just click on the desired and active ASIO driver.

In the future, if a selected DAC is active, and its internal settings are unchanged, the setup mode is skipped when you start the player.

To enter the setup mode, when starting the player, click on the initial screen saver or press the "Enter" button.

When you select the ASIO driver, a settings window appears. Here you can set the initial volume level.

Control.

The player is controlled from the keyboard.

Short keys:

"Esc" – close player

"Tab" – minimize player

"U" or "+" in the keypad – volume increase

"D" or "-" in the keypad – volume decrease

"P" – play

"S" – stop

"N" – the next track

"Space" – play / pause

"O" – open

"C" – clear

"Up" – select a track one position up

"Down" – select a track one position down

"Up" – scroll the playlist up

"Down" – scroll down the playlist

"Shift + Up" – move a track one position up

"Shift + Down" – move a track one position down

"Delete" – delete a track

Other.

The ASIO driver buffer is set on the value recommended by the DAC manufacturer or higher.

You can open tracks only with the same sample rate at the same time.